



Sash Replacement Kit

1. Install balance brackets by screwing them to frame jambs, centering them in the jamb pocket width as shown in figure below at right.
2. Snap the balances over the brackets. The balances should be free-floating to allow proper sash contact. If they bind, reposition the brackets to allow proper play.
3. Apply sash pivots to sash: Sash Pivot Placement: Lower sash pivot is placed 3/8" up from the high side of the bevel, pin down. Upper sash pivot is placed 7/32" up on the check/meeting rail, pin down.
4. Place the pivot pin on the bottom of the top sash into the metal slot in the clutch of the balance at a 90 degree angle to activate the clutch. Repeat for the bottom sash. Where necessary, lubricate the bottom sash track only with silicone spray after finishing to improve operation and tilting.

- Short Sash Pivots (A) are viewed left and right facing the exterior of sash. Refer to "L" or "R" on pivot.
- Long Sash Pivots (B) are not handed and fit on both sides of the sash.



Sash Pivots - We are in the process of transitioning from 'Type A' to 'Type B' Sash Pivot.

Secure with #6 x 3/4"
Phillips Pan Head Screws.

